



| BWJ2~4 | | | | | |
|---|---|---|---|---|---|
| No. | Part Name | No. | Part Name | No. | Part Name |
| 106-2 | Inlet housing assembly | 520-1 | Long round sleeve | 592 | Base |
| 107 | Outlet housing | 520-2 | Short round sleeve Ⅰ | 801 | Motor |
| 112-1 | Deflector | 520-3 | Short round sleeve Ⅱ | 900-1 | Type 1 Non-Metallic Insert Hex Lock Nuts |
| 112-2 | Deflector with shaft | 520-4 | Bushing | 900-2 | Type 1 hex nut |
| 230 | Impeller | 529 | Bearing inner race | 900-3 | Hexagon socket head cap screws |
| 410-1 | Gasket | 550-1 | Adjusting washer | 903 | Bleed cock |
| 412-1 | O-ring sea | 550-2 | Standard spring washer | 905 | Tie rod |
| 433 | Mechanical seal | 550-3 | Standard spring washer | | |