



BWJ8~20

No.	Part Name	No.	Part Name	No.	Part Name
106	Inlet housing assembly	412-2	O-ring seal	900-1	Type 1 Hex Nut
112-1	deflector	433	Mechanical seal	900-2	Type 1 Non-Metallic Insert Hex Lock Nuts
112-2	Final stage deflector	520	Long round sleeve	900-3	Hexagon socket head cap screws
148	Outlet housing	520-1	Short round sleeve	903	Bleed cock
230	Impeller	540	Bushing	905	Tie rod
411	Gasket	592	Base	930-1	Standard spring washer
412-1	O-ring seal	801	Motor	930-2	Standard spring washer